



CAUTION :


Item: **102/246016**

ADULT ASSEMBLY REQUIRED. Hardware contains small screws with sharp points. Keep unassembled parts out of the reach of small children.

Teatr i sklep 2 w 1 /Wooden Theatre and shop 2 in1/Theater und Shop

Instrukcja Montażu Assemble Instruction Montage Instruktion

1.CONTENTS



2.HOW TO ASSEMBLE

